

Spare Parts List HL 1610 S

	Pos.	Part No.
HL 1610 S, Type 3480		
Housing Set incl. Labels	1+2	02816
Switch with Markings (external)	3	02416
Power Cord with Strain Relief	4+5	02723
Power Cord Connector	6	—
Set of 5 Housing Screws	7	02829
PCB/C Block with Switch (internal)	8	02316
Motor/Fan Assembly	9	02216
Heating Element 1300W/120V	10	02116
Switch (internal)	11	02417

Wiring Diagram HL 1610 S

