

CONREVSMA005-R178 ASSEMBLY INSTRUCTIONS

- Strip cable to recommended dimensions.
- 2. Slip heat shrink and crimp ring onto stripped cable.
- Insert the stripped cable through the retaining nut, shield sleeve, and spacer.
- 4. Solder the pin to the center conductor.
- Insert the pin into the pin insulator, then screw the main body onto the retaining nut.
- Wrap the braid around the tail of the body and crimp the ring with a 0.100" hex crimp tool (or one labeled for use with RG-178 cable).
- 7. Use heat shrink to cover crimp.
- 8. Use the nut and washer to secure the connector to a case.

- 1. ALL DIMENSIONS ARE IN INCHES [mm].
- 2. DIMENSIONS APPLY AFTER FINISHING.
- SAFETY BREAK ALL SHARP CORNERS AND EDGES .02 MAXIMUM.
- 4. MANUFACTURE TO BE COMPLIANT WITH EU ROHS DIRECTIVE, USE MATERIALS THAT DO NOT CONTAIN REACH SUBSTANCES OF VERY HIGH CONCERN >1000ppm, AND USE DRC CONFLICT-FREE SOURCED MATERIALS.

WARNING: THIS DRAWING CONTAINS PROPRIETARY INFORMATION THAT IS THE SOLE PROPERTY OF LINX TECHNOLOGIES, AND SHALL BE TREATED AS SUCH. NO DISCLOSURE OR REPRODUCTION OF THIS DOCUMENT IS PERMITTED, IN WHOLE OR IN PART, WITHOUT THE EXPRESS WRITTEN PERMISSION OF LINX TECHNOLOGIES OR ITS DESIGNATED AGENTS.

DESIGNATED AGENTS.

MATERIAL:

TOLERANCES:
.020 [0.50]-200 [5.00]=±.008 [0.20]
.200 [5.00]-1.200 [30.00]=±.016 [0.40]
1.20 [30.0]-4.75 [120.0]=±.024 [0.60]
4.75 [120.0]-12.40 [315.0]=±.040 [1.0]

ANGLES: ±1°

PROJECTION:
ANGLES: ±1°
ANGLES: ±1°

PROJECTION:
DRAWN: B.MURPHY DT: 29-JUN-12

ENGR: S.HOGAN

Linx 159

TITLE:

159 ORT LANE MERLIN, OR 97532

RP-SMA FEMALE BULKHEAD MOUNT CABLE END CRIMP FOR RG178 CABLE